


1. System Architecture


1.1 30K Overall Structure



1.2 Inverter Topology



The following INVERTER 3-phase full-bridge inverter circuit diagram is shown below. By controlling Q1-Q12 in turns, it achieves DC/AC conversion. Through the boost of transformers and filter of the LC filter output, it provides pure sine wave voltage.

Service Manual for Hybrid 30KW PV Inverter



1.3 Model Power Line and signal one wiring Diagram(High-definition drawings attached.)

Diagram of SCR Control Portion



Input Relay:




Diagram of Inverter Control Portion

Service Manual for Hybrid 30KW PV Inverter







Diagram of control board wiring







2.PC Panel






2.1 Introduction of PC Panel

| No. | Latest Ver. | Function (Board name) | Image | Purpose |
|-----|-------------|-----------------------|-------|----------------|
| 1 | 01G | Control Board | | 31-500033-XXG: |




Service Manual for Hybrid 30KW PV Inverter

| | | | | |
|---|-----|-----------------------------------|--------------------------------------------------------------------------------------|----------------|
| 2 | 00G | Power Board |  | 31-500036-XXG: |
| 3 | 00G | Voltage sampling board |  | 31-500032-XXG: |
| 4 | 01G | Inverter Current Sampling Board |  | 31-530215-XXG: |
| 5 | 00G | Battery/PV Current Sampling Board |  | 71-301216-XXG: |





Service Manual for Hybrid 30KW PV Inverter

| | | | | |
|----|-----|-----------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|
| 6 | 00G | Output/ Input Current Sampling Board |  <p>A green printed circuit board (PCB) with various electronic components. It features three large black cylindrical components, likely inductors or transformers, mounted on the board. The board is populated with resistors (R1, R2, R3, Z1, Z2, Z3, Z4), transistors (TR1, TR2, TR3), and other surface components. A barcode label with the number 'A30017100G15L07100100' and a part number '027MBO51203' are visible. A white arrow points to a specific component on the right side.</p> | 31-530216-XXG: |
| 7 | 00G | Inverter Control Board |  <p>A green PCB densely packed with integrated circuits (ICs), resistors, and other electronic components. It has several multi-pin connectors along the top and bottom edges. A small label with the number '027MBO51203' is located in the bottom right corner.</p> | 31-500034-XXG |
| 8 | 00G | SCR Driver Board |  <p>A green PCB with various electronic components, including resistors, capacitors, and integrated circuits. It features several multi-pin connectors along the top and bottom edges. A small label with the number '16-000735-00G(B)' is visible in the top left corner.</p> | 31-500031-XXG: |
| 9 | 00G | Cold Start Button |  <p>A green PCB with a white push-button switch (SW1) and a white connector (CN1). The board is also populated with two silver screws. The part number '16-301596-00G(B)' is printed on the board. A white arrow points to the button.</p> | 71-301596-XXG: |
| 10 | 04G | Model Switching Board |  <p>A green PCB with a multi-position rotary switch (SW2) and a multi-pin connector. The switch has positions labeled 'ON' and 'NO'. The part number '16-302188-00G(A)' is printed on the board. A white arrow points to the switch.</p> | 71-302188-XXG: |



Service Manual for Hybrid 30KW PV Inverter

| | | | | |
|-----------|------------|-------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------|
| <p>11</p> | <p>00G</p> | <p>Output Capacitor Board</p> |  <p>A photograph of a green printed circuit board (PCB) for an output capacitor. It features six large, dark grey, rectangular electrolytic capacitors arranged in a 2x3 grid. The board has white connectors at the bottom and some text printed on it, including '16-301217-00G (B)' and 'BYPASS OP'.</p> | <p>31-530218-XXG:</p> |
| <p>12</p> | <p>00G</p> | <p>Display Screen</p> |  <p>A photograph of a square LCD display screen mounted on a green PCB. The screen is dark and framed by a silver border. The PCB has a multi-pin connector on the right side.</p> | <p>12-400134-XXG:</p> |
| <p>13</p> | <p>00G</p> | <p>Inverter Adapter</p> |  <p>A photograph of a small green PCB inverter adapter. It has several electronic components, including resistors and capacitors. Three wires are connected to it: a white wire, a blue wire, and a red wire, all with red crimp connectors.</p> | <p>71-301212-XXG:</p> |

Service Manual for Hybrid 30KW PV Inverter

| | | | | |
|----|-----|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------|
| 14 | 00G | LED Clicking Board |  <p>A green PCB with four push buttons labeled KEY1 ON, KEY2 OFF, KEY3 UP, and KEY4 DOWN. It also features four LEDs: LED1 LINE Green, LED2 BAT Yellow, LED3 BYP Yellow, and LED4 FAULT Red. Connectors CN1, CN3, and CN4 are visible. A barcode label reads '16-301544-00G' and 'A30154400G15L22100051'.</p> | 71-301544-XXG: |
| 15 | 00G | Communication Board |  <p>A green PCB with various electronic components, including integrated circuits and capacitors. It has several connectors along the top edge. A barcode label at the bottom reads 'A30154400G15L22100051'.</p> | 31-530213-XXG: |
| 16 | 00G | Parallel Board |  <p>A green PCB with a complex layout of components, including capacitors, resistors, and integrated circuits. It features several connectors at the bottom. A barcode label reads 'A30152400G18G13100003'.</p> | 71-301566-XXG: |
| 17 | 00G | Touch Panel Connectors |  <p>A green PCB with three large black connectors labeled (TO SLOT), (TO LCD), and (TO CNTL). It also has a potentiometer and other components. A yellow label reads '41-070278-00G RC 1524'. A barcode label reads 'S30121900G16D14100046'.</p> | Connect with touch panels |

Service Manual for Hybrid 30KW PV Inverter

| | | | | |
|----|-----|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|
| 18 | | SNMPCard |  <p>A photograph of a green printed circuit board (PCB) labeled 'SNMPCard'. It features a central microcontroller chip with a digital display showing '0688' and '066'. A barcode sticker with the number 'A00025807G16F08100139' is attached to the left side. Various electronic components like resistors, capacitors, and connectors are visible on the board.</p> | (Selected Accessory) |
| 19 | 01G | Inverter Power Adapter |  <p>A photograph of a large green PCB for an 'Inverter Power Adapter'. It has a complex layout with numerous components, including several large electrolytic capacitors, integrated circuits, and multiple terminal blocks for wiring. The board is populated with various electronic parts and has a detailed component layout.</p> | 71-301208-XXG |

2.2 LED Indicator on PC Board

| PC Board | Location of LED | Signal | Description |
|-----------------------------------|-----------------|------------|--------------------------------------------------------------------|
| Control Board 31-500033-XXG | LED1 | VD3.3 | Always lighting: +3.3V Voltage supply is normal. |
| | LED3 | DRY-OUT1 | Always lighting: Dry Contact is normal. |
| Power Board 31-500036-XXG | LED1 | VD+12 | Always lighting: +12V Voltage supply is normal. |
| SCR Driver Board 31-500031-XXG | LD7 | BATDIS.SCR | Always lighting: Battery discharge driver signal output indication |
| | LD8 | BATCHG.SCR | Always lighting: Battery discharge driver signal output indication |

Service Manual for Hybrid 30KW PV Inverter

| | | | |
|---------------------------------|------|------------|-------------------------------------------------------------------|
| | LD9 | DRV.BYP R | Always lighting: Bypass R phase driver signal output indication |
| | LD10 | DRV.OP R | Always lighting: Output R phase driver signal output indication |
| | LD15 | DRV.OP T | Always lighting: Output T phase driver signal output indication |
| | LD11 | DRV. INV S | Always lighting: Inverter S phase driver signal output indication |
| | LD16 | DRV.INV T | Always lighting: Inverter T phase driver signal output indication |
| | LD12 | DRV.INV R | Always lighting: Inverter R phase driver signal output indication |
| | LD13 | DRV.BYP S | Always lighting: Bypass S phase driver signal output indication |
| | LD17 | DRV.BYP T | Always lighting: Bypass T phase driver signal output indication |
| | LD14 | DRV.OP S | Always lighting: Output S phase driver signal output indication |
| Panel Keyboard 71-301544-XXG | LED3 | Solid On | Output is powered by utility in line mode. |
| | | Flashing | Output is powered by battery or PV in battery mode. |
| | LED1 | Solid On | Battery is fully charged. |
| | | Flashing | Battery is charging. |
| | LED2 | Solid On | PV is connected and can work normally. |
| | | Flashing | PV is connected but the voltage is too low. |
| | LED4 | Solid On | Fault occurs in the inverter. |
| | | Flashing | Warning condition occurs in the inverter. |

2.3 Function of connectors on PC board

| Starting Point (From) | | Ending Point (To) | | Function of Connectors |
|--------------------------------|----------|------------------------|----------|--------------------------------------------|
| Name of PC Board | Location | Name of PC Board | Location | |
| Control Board 31-500033-XXG | CN39 | Power Board | CN2 | The system is powered from DC power supply |
| | CN13 | Inverter Control Board | CN13 | Controlled by inverter |
| | CN58 | LED Click Board | CN4 | Controlled by panel indicators |
| | CN57 | LED Click Board | CN3 | Driver LCD indication |
| | CN54 | Power Board | CN5 | High frequency power supply |
| | CN14 | Voltage Sampling Board | CN6 | A/D Signal Sampling |
| | CN16 | Inverter Current | CN1 | Inverter current |

Service Manual for Hybrid 30KW PV Inverter


| | | | | |
|-----------------------------------------|------|-----------------------------------------------|------|------------------------------------------|
| | | Sampling Board | | detection |
| | CN17 | Output Current Sampling Board | CN1 | Output current detection |
| | CN15 | Battery Current Sampling Board | CN1 | Battery charge and discharge detection |
| | CN12 | SCR Driver Board | CN1 | SCR Control |
| | CN3 | Inverter transformer Thermocouple | --- | Over Temperature Protection |
| | CN4 | Battery SCR NTC | --- | Over Temperature Protection |
| | CN5 | STS SCR NTC | --- | Over Temperature Protection |
| | CN8 | IGBT NTC(Left SINK) | --- | Over Temperature Protection |
| | CN2 | IGBT NTC(Right SINK) | --- | Over Temperature Protection |
| | CN1 | PFC.TEMP NTC | --- | Over Temperature Protection |
| | CN59 | Communication Board | CN2 | Dry contact input/output signal |
| | CN53 | Communication Board | CN1 | External communication RS232/485 |
| | CN41 | SNMPCard | --- | SNMP Card Communication |
| | CN46 | Parallel Board | CN46 | Parallel Communication Signal |
| | CN20 | Model Switching Board | CN21 | Model Setting and Version Identification |
| | CN23 | Fan Control Board | CN10 | Fan Control Signal |
| | CN22 | INPUT Current Sampling Board | CN1 | Current Sampling Board |
| | P1 | Software Upload Switch in communication ports | --- | Update MCU Usage |
| Voltage Sampling Board 31-500032-XXG | CN1 | Battery terminals +/- and BUT capacitors +/- | --- | BUS and Battery Voltage Detecting |
| | CN2 | Utility switch (front point) | --- | Utility Voltage Sampling |
| | CN3 | Output switch (front point) | --- | Output Voltage Sampling |
| | CN4 | Inverter transformers | --- | Inverter Voltage Sampling |

Service Manual for Hybrid 30KW PV Inverter

| | | | | |
|------------------------------|-----------|---------------------------|------|-------------------------------|
| | | second side | | |
| | CN6 | Control Board | CN14 | A/D Signal Sampling |
| Power Board 31-500036-XXG | CN4 | SPS Transformer 1 | --- | Main Power Supply |
| | CN1 | Battery Terminals +/- | --- | DC Power Supply |
| | CN7 | Cold Start Click Board | CN1 | Cold Start |
| | CN2 | Control Board | CN39 | System DC Power Supply |
| | CN5 | Control Board | CN54 | Offer high frequency power |
| | CN3 | Parallel Board | CN18 | DC Power Supply |
| | CN11~CN16 | Fan | --- | Fan Control |

3.INVERTER Device

3.1 30K Inner View




1. INV module
2. INV transformer
3. INV filter capacitor
4. OP/BY/INV SCR
5. Input inductor
6. SPS (Switching power supply) board
7. INV driver board
8. Control board
9. SCR driver board


3.2 30K main power devices

IGBT module:

Service Manual for Hybrid 30KW PV Inverter



Critical components of OP/BYPASS/INV SCR (Red Box)
Critical components of BAT SCR (Yellow Box)



Critical components of BAT fuse



4. Troubleshooting

4.1 Static check

4.1.1 General checkpoint

Check the fuse

Check IGBT, diode


Check the power line and the signal line wiring



Check other key component parameters.

4.1.2 Critical inspection of critical components

| Check the components | | Equipment function | Reference | Unqualified condition |
|----------------------|----------------|--------------------|---------------------|-------------------------------|
| Battery Fuse | F | Resistor | $<1\Omega$ | Open Circuit |
| Thyristors Module | SCR (4,5)(6,7) | Resistor | $\approx 16\Omega$ | Short circuit of Open Circuit |
| IGBT Module | (G,E) | Resistor | ∞ | Short circuit |
| | (G,E) | Capacitor | 40nF | Short circuit of Open Circuit |
| Discharge Resistor | R | Resistor | $\approx 10K\Omega$ | Short circuit of Open Circuit |
| Slow Start Resistor | R | Resistor | $\approx 50\Omega$ | Short circuit of Open Circuit |
| BUS Capacitor | (+,-) | Resistor | ∞ | Short circuit |

The following are the 30K packages for each module





4.1.3 Static check of inverter control board

| | | | | |
|--------------------------------------------|-------|----------|----------------------|-------------------------------|
| T25/26 | (S,D) | Diode | $\approx 0.544v$ | Short circuit or open circuit |
| | (S,G) | Diode | $\approx 0.633v$ | Short circuit or open circuit |
| | (S,G) | Resistor | $\approx 418K\Omega$ | Short circuit or open circuit |
| U50/51/52/53/54/55/56/57/58/59/60/61/62/70 | (3,4) | Diode | $\approx 0.622v$ | Short circuit or open circuit |
| | (6,4) | Diode | $\approx 0.618v$ | Short circuit or open circuit |
| | (4,3) | Resistor | $\approx 222K\Omega$ | Short circuit or open circuit |
| | (2,1) | Diode | $\approx 0.617v$ | Short circuit or open circuit |
| | (2,8) | Diode | $\approx 0.618v$ | Short circuit or open |

Service Manual for Hybrid 30KW PV Inverter

| | | | | |
|-----------------------------------------------------------------------------------------|-------|----------|----------------------|-------------------------------|
| | | | | circuit |
| | (1,2) | Resistor | $\approx 221K\Omega$ | Short circuit or open circuit |
| R3/5/31/29/234/247/83/81/107/109/135/133 | --- | Resistor | $\approx 0\Omega$ | Open circuit |
| D74/71/65/68/85/82/76/79/84/81/75/78/72/69/63/66/100/101/102/91/72/70/64/67/86/83/80/77 | (A,K) | Diode | $\approx 0.221v$ | Short circuit or open circuit |

4.1.6 Status Check of Power Board

| Check the components | | Equipment Function | Reference | Unqualified condition |
|----------------------|-------------|--------------------|-----------------------|-------------------------------|
| Q2/Q6 | (S,D) | Diode | $\approx 0.508v$ | Short circuit or open circuit |
| | (S,G) | Diode | $\approx 0.336v$ | Short circuit or open circuit |
| | (S,G) | Resistor | $\approx 9.36K\Omega$ | Short circuit or open circuit |
| D3/4 | (A,K) | Diode | $\approx 0.525v$ | Short circuit or open circuit |
| D2 | (A,K) | Diode | $\approx 0.449v$ | Short circuit or open circuit |
| D10 | (P,N) (P,N) | Diode | $\approx 0.791v$ | Short circuit or open circuit |
| ZD10/14/15/16 | (A,K) | Diode | $\approx 0.715v$ | Short circuit or open circuit |
| R14 | | Resistor | $\approx 1.5\Omega$ | Short circuit or open circuit |

4.1.7 SCR Static check for driver board

| Check the components | | Equipment Function | Reference | Unqualified condition |
|--------------------------------------------------------------|-------|--------------------|---------------------|-------------------------------|
| Q7-Q17 | (S,D) | Diode | $\approx 0.466v$ | Short circuit or open circuit |
| | (S,G) | Diode | $\approx 0.635v$ | Short circuit or open circuit |
| | (S,G) | Capacitor | $\approx 10K\Omega$ | Short circuit or open circuit |
| Z7-Z17 | (A,K) | Diode | $\approx 0.601v$ | Short circuit or open circuit |
| D35/32/67/74/75/76/68/69/40/41/43/45/47/49/58/59/55/57/53/51 | (A,K) | Diode | $\approx 0.497v$ | Short circuit or open circuit |
| D39/42/46/60/54/50/72/70/65/37/34 | (A,K) | Diode | $\approx 0.595v$ | Short circuit or open circuit |

4.1.8 10-200K Static check of voltage sampling board

| Check the components | Equipment Function | Reference | Unqualified condition |
|----------------------|--------------------|-----------|-----------------------|
|----------------------|--------------------|-----------|-----------------------|

| | | | | |
|------|-------|----------|---------|-------------------------------|
| Q17 | (C,B) | Diode | ≈0.673v | Short circuit or open circuit |
| | (E,B) | Diode | ≈0.674v | Short circuit or open circuit |
| | (E,B) | Resistor | ≈10KΩ | Short circuit or open circuit |
| T1 | (B,C) | Diode | ≈0.681v | Short circuit or open circuit |
| | (B,E) | Diode | ≈0.682v | Short circuit or open circuit |
| | (B,E) | Resistor | ≈10KΩ | Short circuit or open circuit |
| D1 | (A,K) | Diode | ≈0.101v | Short circuit or open circuit |
| ZD12 | (A,K) | Diode | ≈0.679v | Short circuit or open circuit |

4.2 Status Check

4.2.1 General checkpoint

Check the LED status

Check the LCD display status (with or without alarm message)


Check information of LCD display voltage measurement

Check the critical driver signals, such as IGBT driver signals, SCR driver signals

Check the rectifier with the inverter voltage/current waveform during slow start.

4.2.2 Confirm control board power operation


Check the Power supply

| No. | Probe -(Ground) | Probe + | Testing Result | Waveform |
|-----|--------------------|---------------------------------------------|-------------------------------|--------------------------------------------------------------------------------------|
| 1 | TP1/TP2 | CN6-1 | -12V | |
| 2 | TP1/TP2 | CN6-3 | +12V | |
| 3 | TP1/TP2 | CN11-2 | +5V | |
| 4 | TP1/TP2 | TP4 | +1.9V | |
| 5 | TP1/TP2 | TP5 | +3.3V | |
| 6 | TP1/TP2 | TP7 | +1.5V | |
| 7 | TP1/TP2 | TP3 | +3V | |
| 8 | CN54-1 | CN54-2 High Frequency Power Supply | Vmax=18.4V; Freq.=92.49kHz |  |

a) Testing Measures (refer to section 5)

b) Check the driver signal (refer to section 5)

Service Manual for Hybrid 30KW PV Inverter




Control Board Testing Points

4.2.3 Confirmation of Operation of Power Board

| No. | Probe-(Ground) | Probe + | Testing Result | Waveform |
|-----|----------------|---------|-------------------------------|----------|
| 1 | TP3 | TP1 | -15V | |
| 2 | TP3 | TP2 | -12V | |
| 3 | TP3 | TP6 | +12V | |
| 4 | CN3-1 | CN3-2 | Vmax= 18V; Freq.=92.49kHz; | |

Service Manual for Hybrid 30KW PV Inverter

| | | | | |
|---|-----|------|---------------------------------------------------------------------------|--|
| 5 | TP8 | TP7 | +15V | |
| 6 | TP8 | D3-K | Effective value is about 360V (depending on the actual mains voltage). | |
| 7 | TP3 | TP9 | +5V | |





Testing Points on Power Board

4.2.4 SCR Confirmation of Driver Board Power Operation


| No. | Probe-(ground) | Probe + | Testing Result | Waveform |
|-----|----------------|--------------------|---------------------------------------------------------------|----------|
| 5 | TP4 | TP3 (OP OSC) | $V_{max} = +5V;$ Freq.=22.45kHz; Duty cycle=13% | |

Service Manual for Hybrid 30KW PV Inverter

| | | | |
|---|-----------------------------------------------------------------|---------------------------------------------------------------------------------|------------------------------------------------------------------------------------|
| 6 | CN3/4/5/6/16/17/9/19/20 CN14/18 SCR Driver Signals | Vmax= +1.6V; The Status of LED Lights, see section 2.2 for details |  |
|---|-----------------------------------------------------------------|---------------------------------------------------------------------------------|------------------------------------------------------------------------------------|




4.2.5 Confirmation of Power Operation of inverter control panel


| No. | Probe-(ground) | Probe+ | Testing result | Waveform |
|-----|-----------------|-----------------|------------------------------------------------------|--------------------------------------------------------------------------------------|
| 1 | T25-S | T25-D | +12V_PW |  |
| 2 | T25-S | D43-K | +12V_D | |
| 3 | T25-S | T25-G | Vmax= +12.4V; Freq.=71.98kHz; Duty cycle=35.7% | |
| 4 | CN1-2 (RLH-) | CN1-1 (RLH+) | 12V+/-5% -12V+/-5% | |
| 5 | CN2-2 (RLL-) | CN2-1 (RLL+) | 12V+/-5% -12V+/-5% | |
| 6 | CN4-2 (RNH-) | CN4-1 (RNH+) | 12V+/-5% -12V+/-5% | |
| 7 | CN3-2 | CN3-1 | 12V+/-5% | |

Service Manual for Hybrid 30KW PV Inverter

| | | | |
|----|----------|-----------|-----------|
| | (RNL-) | (RNL+) | -12V+/-5% |
| 8 | CN5-2 | CN5-1 | 12V+/-5% |
| | (SLH-) | (SLH+) | -12V+/-5% |
| 9 | CN6-2 | CN6-1 | 12V+/-5% |
| | (SLL-) | (SLL+) | -12V+/-5% |
| 10 | CN8-2 | CN8-1 | 12V+/-5% |
| | (SNH-) | (SNH+) | -12V+/-5% |
| 11 | CN7-2 | CN7-1 | 12V+/-5% |
| | (SNL-) | (SNL+) | -12V+/-5% |
| 12 | CN9-2 | CN9-1 | 12V+/-5% |
| | (TLH-) | (TLH+) | -12V+/-5% |
| 13 | CN10-2 | CN10-1 | 12V+/-5% |
| | (TLL-) | (TLL+) | -12V+/-5% |
| 14 | CN12-2 | CN12-2 | 12V+/-5% |
| | (TNH-) | (TNH+) | -12V+/-5% |
| 15 | CN11-2 | CN11-1 | 12V+/-5% |
| | (TNL-) | (TNL+) | -12V+/-5% |
| 16 | CN16-2 | CN16-1 | 12V+/-5% |
| | (BOOST-) | (BOOST +) | -12V+/-5% |
| 17 | CN15-2 | CN15-1 | 12V+/-5% |
| | (BUCK-) | (BUCK +) | -12V+/-5% |



Service Manual for Hybrid 30KW PV Inverter



Testing points of Inverter control board


5. INVERTER Check after Assembly or maintenance

5.1 Preparation


Make sure that the input, output and PV are off, and the battery is not damaged.
 Check if Power rate components and wiring are significantly wrong.
 Confirm that the input and output wiring (R-N/S-N/T-N/R-S/S-T/T-S) is not short-circuited.

5.2 Measure the IGBT driver signal of the inverter

- Only close the input switch (to confirm the PV and the battery switch are off.)
- Press "Pulse Test" in the "Factory Test" Menu as below.
-



- Use the oscilloscope probe to measure the waveform between the IGBT side and the IGBT driver resistor of the inverter driver board and the corresponding driver ground, as shown in the diagram below:





IGBT Open waveform IGBT Close waveform

e) Confirm the waveform of the 6-arm driver signals. The maximum value is 15V, the minimum value is -10V.

5.3 Voltage and current calibration

5.3.1 The machine shuts down and cuts off the mains supply to short-circuit the output UVWN, and then Connect the machine to mains and restart it. The operation steps of calibrating the zero bias of the output voltage and current inverter voltage and current (the regulated range voltage is less than 0.2V and the current is less than 0.2A) are as follows

5.3.2 Please follow the procedure below to enter "calibration" in the "Factory Setup" Menu




(Note: if there is no password, you can't calibrate the parameter)

5.3.3 The list of parameters need to be corrected.

| | |
|----------------------------------|-------------|
| Inverter voltage approaches zero | R-N,S-N,T-N |
| Output voltage approaches zero | R-N,S-N,T-N |
| Input Voltage | R-N,S-N,T-N |
| Output Voltage | R-N,S-N,T-N |
| Inverter Voltage | R-N,S-N,T-N |
| BUS Voltage | --- |
| Battery Voltage | --- |
| Output Current | R,S,T |
| Inverter Current | R,S,T |
| Recharging Current | --- |
| Charging Current approaches zero | --- |

5.3.4 The voltage of inverter approaches zero, the output voltage is zero and parameter calibration.



- a) Only switch on the input and the INVERTER operates in standby mode.
- b) Follow the procedure in 5.4.2 to enter the parameter calibration below.



- c) Press <ENTER>. the adding value on the right "XXXX" will flash. You can use <UP> and <DOWN> to adjust the display value on the left side of the LCD to zero (Note: The left side of the LCD display Value will change during calibration)
- d) Press <ENTER> to confirm the setting (Do not use <ECS>, it can't save the data.)
- e) Correct the voltage and output voltage of the 3-phase inverter in the same way.

5.3.5 Parameter Calibration of Input, output voltage


- a) INVERTER is operating in inverter mode, no load is connected. Follow the procedure in 5.3.2 to enter the parameter calibration below.



- b) Press <ENTER>, the "XXXX" the adding value on the right will flash. You can use <UP>, and <DOWN> to adjust the LCD display to match the actual value of the multimeter measurement. (Note: The measured value on the left side will change during calibration)
- c) Press <ENTER> to confirm the setting.
- d) Correct the 3-phase input voltage and output voltage in the same way.

5.3.6 Parameter Calibration of inverter voltage

- a) The INVERTER operates in inverter mode with 100% (or close to 100%) output.
- b) Follow the procedure in 5.3.2 to enter the parameter calibration below.




- c) Press <ENTER>, the adding value on the right will flash. You can use <UP>, and <DOWN> to adjust the LCD display to match the actual value of the multimeter measurement. (Note: the

calibration can only change the actual measured value, the measured value on the left side of the LCD display will not be changed.)

- d) Press <ENTER> to confirm the setting. (Do not use <ESC>, it can't save the data.)
- e) Use the same method to correct inverter voltage of the other two-phase.

5.3.7 Parameter Calibration of Bus Voltage, battery voltage



- a) The INVERTER is operating in inverter mode without any load.
- b) Follow the procedure in 5.3.2 to enter the parameter calibration below.



- c) When press <ENTER>, the adding value on the right "XXXX" will flash. You can use <UP>, and <DOWN> to adjust the LCD display to match the actual value of the multimeter measurement. (Note: The measured value on the left side will change during calibration)
- d) Press <ENTER> to confirm the setting. (Do not use <ESC>, it can't save the data.)
- e) Use the same method to correct the BUS voltage and battery voltage.

5.3.8 Parameter Calibration of Output current, and Inverter current

- a) The INVERTER operates in inverter mode with 100% (or close to 100%) output.
- b) Follow the procedure in 5.3.2 to enter the parameter calibration below.




- c) When press <ENTER>, the adding value on the right "XXXX" will flash. You can use <UP>, and <DOWN> to adjust the LCD display to match the actual value of the multimeter measurement. (Note: The measured value on the left side will change during calibration)
- d) Press <ENTER> to confirm the setting. (Do not use <ESC>, it can't save the data.)
- e) Use the same method to correct the output and inverter current.


5.3.9 Parameter Calibration of charge current, charge current zero deviation

- a) The INVERTER operates in inverter mode and output without load.
- b) Set the charging current based on the operation procedure.

Service Manual for Hybrid 30KW PV Inverter




c) Follow the procedure in 5.3.2 to enter the parameter calibration below.



- d) Press <ENTER>, the adding value on the right will flash. You can use <UP>, and <DOWN> to adjust the LCD display to match the actual value of the multimeter measurement. (Note: the calibration can only change the actual measured value, the measured value on the left side of the LCD display will not be changed.)
- e) Press <ENTER> to confirm the setting. (Do not use <ESC>, it can't save the data.)


Service Manual for Hybrid 30KW PV Inverter

5.3.10 In the measurement menu below, check the difference between the LCD display value and the actual measure value of the multimeter/ current clamp and control within 1%.



6. How to Replace Key Parts

6.1 Circuit board (To take inverter power board as an example)




Remove the screws.




Replace the IGBT which was coated with heat dissipation, and damaged board. Put the wire back. Please be noted that the mounting position of the IGBT should be placed correctly.

6.2 IGBT Module



Remove the screws.



Remove the screws and replace the module

6.3 SCR Module




Remove the screws.

To take a SCR as an example



Remove the screws and replace the damaged module. Please be noted that the thermal paste should be coated evenly, and the polarity of the module pin should not be reversed.

6.4 Cooling Fans



Remove the screws from the top



Change the broken fans



7.Other

7.2 Troubleshooting

a. Warning Code

| Code | Description | Possible Reasons |
|------|---------------------------|-------------------------------------------------------------------------------------------|
| 01 | Battery is not connected. | Check if the battery is connected, the polarity is correct. |
| 10 | Mains Input Phase error | Check if the sequence of mains input phase is correct. |
| 12 | Overload | Reduce the load to the range of rated load. |
| 11 | EPO Open circuit | No short circuit EPO interface. |
| 17 | SolarLoss | PV voltage is too low. |
| 13 | DCDCOverTemp | Reduce the load or ambient operating temperature of the machine. |
| 18 | Inv0TempOver | |
| 19 | OPSCRTempOver | |
| 20 | Inv1TempOver | |
| 21 | BatSCRTempOver | |
| --- | Change Battery | Reach the setting value of batter lifespan. Please replace the battery. |
| --- | EEPROM Error | Restart the INVERTER. If you can't eliminate the error, please replace the control panel. |
| --- | Battery Testing Fails | The battery voltage is too low. Charge the battery. |
| --- | Parallel Wires loss | Check if the parallel communication cables is connected well and restart the INVERTER. |

b. Fault Code

| Code | Description | Possible Reasons |
|------|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| 02 | BUS High Voltage | It may be caused from frequent transient load. |
| 03 | BUS Low Voltage | Reduce the load. Please increase the charge current of the battery. |
| 04 | Inverter Soft start fails | Check if there is any damage in the inverter module. Restart the INVERTER. If the problem still exists, please contact service center. |
| 34 | Inverter High Voltage | Disconnect the load. If the INVERTER is normal after restart, please check the load. |
| 33 | Inverter Low Voltage | Disconnect the load. If the problem remains after restart, please contact service center. |
| 40 | R Phase Inverter Short | Disconnect the load. If the INVERTER is normal after restart, please check the load. |
| 41 | S Phase Inverter Short | Disconnect the load. If the INVERTER is normal after restart, please check the load. |
| 42 | T Phase Inverter Short | Disconnect the load. If the INVERTER is normal after restart, please check the load. |
| 43 | RS Phase Inverter Short | Disconnect the load. If the INVERTER is normal after |

Service Manual for Hybrid 30KW PV Inverter

| | | |
|-----|-------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | | restart, please check the load. |
| 44 | ST Phase Inverter Short | Disconnect the load. If the INVERTER is normal after restart, please check the load. |
| 45 | TR Phase Inverter Short | Disconnect the load. If the INVERTER is normal after restart, please check the load. |
| 05 | Inverter Overcurrent | Disconnect the load. If the INVERTER is normal after restart, please check the load. |
| --- | R Phase Inverter IGBT overcurrent | Disconnect the load. If the INVERTER is normal after restart, please check the load. |
| --- | S Phase Inverter IGBT overcurrent | Disconnect the load. If the INVERTER is normal after restart, please check the load. |
| --- | T Phase Inverter IGBT overcurrent | Disconnect the load. If the INVERTER is normal after restart, please check the load. |
| --- | Wrong wiring | Disconnect all power switches on the INVERTER and check the wiring. |
| 46 | Temp Over | Reduce the load or the ambient operating temperature. |
| 47 | | |
| 48 | | |
| 49 | | |
| 50 | | |
| 51 | | |
| 81 | Processor communication failure | Restart the INVERTER. If the problem is still existing, contact the service center. |
| 23 | Overload | Reduce the loads |
| --- | Synchronous action line error | <ol style="list-style-type: none"> 1. If the parallel communication cable is connected well, please restart the INVERTER. 2. Re-plug the parallel communication cable, and check if the connection is proper. Then restart the INVERTER. |
| --- | Wrong parallel line | |
| 80 | CAN Communication failure | |
| 82 | Parallel line lost | |
| --- | Inconsistent output voltage | Use multimeter to measure if the output voltage of each stand-alone INVERTER is consistent. |
| 71 | Different parallel version | Contact the service center to update the version. |
| --- | Synchronous action line lost | Turn off the INVERTER. Re-plug the parallel communication cable. Check if the connection is proper. Then restart the INVERTER. |
| --- | Inconsistent parallel parameter | In standby mode, compare the parameters of the parallel INVERTERs, and correct them to same parameter. |
| 17 | Interruption of DSP and MCU communication | Restart the INVERTER. If the problem is still existing, contact the service center. |
| 18 | Firmware is not compatible | Restart the INVERTER. If the problem is still existing, contact the service center. |
| 22 | Battery High Voltage | Check if the voltage of batter is normal. |

7.3 inverter module driver line (Attached with the high-definition drawings)





Diagram of Inverter IGBT driver line connection

7.4 Inquire Software Versions

In the main screen, press <ENTER> to enter the information in the setup menu. The operation process is as below.



From the top to bottom, MCU version/ DSP version/LCD version

7.5 Setting of Recharge Current

After setting the battery capacity, the maximum charging current of the battery will be automatically set based on $0.2 * C$ (The C represents the battery capacity). Set the nominal charging current in the setting menu with the service passwords in 5.3.9.


7.6 INVERTER System Failure Restore

- On the LCD screen of INVERTER2, press <ENTER> and go to "Control" in the main menu, and then press <ENTER> and select "Turn Off" and confirm the selection.
- Disconnect the output switch.
- Disconnect input switch
- Disconnect the PV switch
- Disconnect the battery switch
- Restore the INVERTER


7.7 Download of History Record

- Prepare one notebook, and connect it with RS232 on the USB communication board.
- Open the software SolarPower, please click "View" and the following interface shows.

Service Manual for Hybrid 30KW PV Inverter




c. Take "Fault date log" as an example . If you need to retrieve the data record, please click "load." when all data are recorded, they will be shown in the C square marked below.




d. If you need to export the history, click "export" and then create the file name. Select the file format and save it.

Service Manual for Hybrid 30KW PV Inverter



e. After executing the operation above, the user will see XLS file. Double click the files and you will see the history record.



7.8 Power Cable Connection

7.8.1 Preparation


Before connecting to AC utility, please install a separate AC circuit breaker between inverter and AC utility. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current of AC input.

WARNING! It is very important for system safety and efficient operation to use appropriate cable for battery connection. To reduce risk of injury, please use the proper recommended cable size as below.


| | |
|--------------------------------------------|--------|
| Nominal Grid Voltage | 230VAC |
| Conductor cross-section (mm ²) | 8 |
| AWG no. | 8 |


7.8.2 Connecting to the AC Utility

The interior view is shown below.



Ring terminal:



 → **Ground (yellow-green)**

R Phase → **LINE (black)**

Y Phase → **LINE (gray)**

B Phase → **LINE (brown)**

N → **Neutral (blue)**


Connect AC Utility power cable, please refer the following table.

| Wire Size | Ring Terminal | | | Torque value |
|-----------|-----------------------|------------|--------|--------------|
| | Cable mm ² | Dimensions | | |
| | | D (mm) | L (mm) | |
| 8 AWG | 8 | 8.4 | 29 | 12.0 Nm |


CAUTION: To prevent risk of electric shock, ensure the ground wire is properly earthed before operating this hybrid inverter no matter the grid is connected or not.

7.8.3 PV Module (DC) Connection

PV wiring diagram is as follows:



Ring terminal:



Check correct polarity of connection cable from PV modules and PV input connectors . Then,connect positive pole(+)
of connection cable to positive pole(+) of PV input connector .Connect negative pole(-) of connection cable to negative pole(-) of PV input connector.

Connect PV Module power cable, please refer the following table.

| Wire Size | Ring Terminal | | | Torque value |
|-----------|-----------------------|------------|--------|--------------|
| | Cable mm ² | Dimensions | | |
| | | D (mm) | L (mm) | |
| 6 AWG | 14 | 8.4 | 32 | 12.0 Nm |


Recommended Panel Configuration

| Solar Panel Spec. (reference) | # PV modules | Q'ty of panels | Total Input Power |
|--------------------------------------------------------------------------------------------|--------------------------------------------------|----------------|-------------------|
| | (Min in serial: 12pcs; Max. in serial: 21pcs) | | |
| - 300Wp - Vmp: 36.7Vdc - Imp: 6.818A - Voc: 44Vdc - Isc: 7.636A - Cells: 72 | 21pcs in serial | 21pcs | 6300W |
| | 21 pcs in serial, 5 strings in parallel | 105pcs | 31500W |
| | 21 pcs in serial, 7 strings in parallel | 147pcs | 44100W |
| | 19 pcs in serial, 8 strings in parallel | 152pcs | 45600W |

7.8.4 Battery Connection

RED cable to the positive terminal(+);

BLACK cable to the negative terminal(-);




WARNING! It is very important for system safety and efficient operation to use appropriate cable for battery connection. To reduce risk of injury, please use the proper recommended cable size as below.

| | |
|--------------------------------------------|------|
| Nominal Battery Voltage | 384V |
| Conductor cross-section (mm ²) | 22 |
| AWG no. | 4 |

7.8.5 Load(AC Output) Connection

The interior view is shown below.



Ring terminal:



→ **Ground (yellow-green)**

R Phase→ **LINE (black)**

Y Phase→ **LINE (gray)**

B Phase→ **LINE (brown)**

N→ **Neutral (blue)**

Recommended wire and terminal size:

| Wire Size | Ring Terminal | | | Torque value |
|-----------|-----------------------|------------|--------|--------------|
| | Cable mm ² | Dimensions | | |
| | | D (mm) | L (mm) | |
| 8 AWG | 8 | 8.4 | 29 | 12.0 Nm |

WARNING! It is very important for system safety and efficient operation to use appropriate cable for AC connection. To reduce risk of injury, please use the proper recommended cable size as below.

| | |
|--------------------------------------------|--------|
| Model | 30KW |
| Nominal Grid Voltage | 230VAC |
| Conductor cross-section (mm ²) | 8 |
| AWG no. | 8 |

7.9 RS232 Communication

Connect the computer with USB to RS232 (or use the supplied USB cable) and connect with INVERTER communication board. Click the SolarPower on your computer. At this moment, The serial number of the machine is always displayed in the upper left corner of the software and it presents the connection is completed. Enter the monitoring interface as below.

Service Manual for Hybrid 30KW PV Inverter




Fig1 in Inverter mode



Fig2 in Bypass with AC charging Mode



Fig3 in Standby with PV charging mode

7.10 SNMP Communication Card


Features of SNMP Web Pro:

- a. Open monitor via Web Browser.
- b. Offer SNMP MIB to monitor Inverter status.
- c. Automatically detect and exchange 10M/100M Fast Ethernet.
- d. Supported protocol such as TCP/IP, UDP, SNMP, SMTP, SNTP, HTTP, HTTPS, SSL, SSH, TELNET, IPV4/IPV6, DHCP and so on.
- e. Able to store more than 200,000 threads of event log, including Inverter warnings, faults and EMD warnings, operation data logs from web users or SolarPower pro users. It will be stored safely without data loss even when power failure occurs.
- f. Support daily reports for event log and data log.
- g. Simultaneously upload UPS data to http servers.
- h. Support EMD monitoring and SMS service.
- i. Set with real-time clock to record log by date and keep running up to 7 days even without power connection.




Please install SNMP Web Manager then enter specific IP address to search all SNMP devices in LAN. Open the monitoring page by double-clicking on the IP address.

Service Manual for Hybrid 30KW PV Inverter



Status



Inverter setting

Service Manual for Hybrid 30KW PV Inverter

SNMP Web Pro 1.1 Parameters setting Login Guest

Information
Status
Power statistic
Basic information

Inverter setting
Parameters setting
MyPower Management

Control
Real-time control

System configuration
Web
E-mail
SMS
Upload
Event action
System time
SNMP configuration

Log
Event log
Data log

Help
Serial Port Debug
Firmware Upgrade

Alarm control: Enable Disable
Alarm at Standby mode: Enable Disable
Alarm at battery mode: Enable Disable

Parallel for output: Enable Disable
Generator as AC source: Enable Disable
Wide AC input range: Enable Disable

***Note:Need factory password.** [Login](#)

| | |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Min grid-connected voltage: <input type="text" value="184.0"/> V <input type="button" value="Apply"/> Max grid-connected voltage: <input type="text" value="264.5"/> V <input type="button" value="Apply"/> Min grid-connected frequency: <input type="text" value="47.4"/> Hz <input type="button" value="Apply"/> Max grid-connected frequency: <input type="text" value="51.5"/> Hz <input type="button" value="Apply"/> | The waiting time before grid connection: <input type="text" value="5"/> Sec <input type="button" value="Apply"/> Max feed-in power: <input type="text" value="1000"/> W <input type="button" value="Apply"/> feed-in power factor: <input type="text" value="100"/> % <input type="button" value="Apply"/> |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

| | |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Voltage range for PV input Max. voltage: <input type="text" value="950.0"/> V <input type="button" value="Apply"/> Min. voltage: <input type="text" value="450.0"/> V <input type="button" value="Apply"/> Voltage range for MPPT Max. voltage: <input type="text" value="900.0"/> V <input type="button" value="Apply"/> Min. voltage: <input type="text" value="460.0"/> V <input type="button" value="Apply"/> Max. charging Current: <input type="text" value="3.0"/> A <input type="button" value="Apply"/> | Battery cut-off discharging/re-discharging voltage when Grid is available Cut-off discharging voltage: <input type="text" value="384.0"/> V <input type="button" value="Apply"/> Re-discharging voltage: <input type="text" value="432.0"/> V <input type="button" value="Apply"/> Battery cut-off discharging/re-discharging voltage when Grid is unavailable Cut-off discharging voltage: <input type="text" value="336.0"/> V <input type="button" value="Apply"/> Re-discharging voltage: <input type="text" value="384.0"/> V <input type="button" value="Apply"/> |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

Start LCD screen-saver after: Sec
Feeding grid power calibration R: W
Feeding grid power calibration S: W
Feeding grid power calibration T: W

Max.battery discharge current in hybrid mode: A

Service Manual for Hybrid 30KW PV Inverter

Control Interface

SNMP Web Pro 1.1 Real-time control Login Guest

AC output: On Off

If [Active Li-Fe battery while commissioning] is selected in parameters setting, AC output will be cut off when this action is executed.

Event Journal

SNMP Web Pro 1.1 Event log Login Guest

02_2018.csv Apply Delete

| Time | Event name | Event source | Client IP |
|---------------------|----------------------------------------------------------------------|--------------|-----------------|
| 02/23/2018 15:49:30 | Enable/disable audible alarm | Web Browser | 192.168.107.148 |
| 02/23/2018 15:53:05 | Solar input 1 voltage exceed the acceptable range | MCU Polling | ---- |
| 02/23/2018 15:53:06 | Solar input 1 voltage exceed the highest level | MCU Polling | ---- |
| 02/23/2018 15:53:06 | AC input voltage lower than the lowest level of AC feeding voltage | MCU Polling | ---- |
| 02/23/2018 15:53:06 | AC input voltage lower than the lowest level of AC feeding frequency | MCU Polling | ---- |
| 02/23/2018 15:53:06 | AC input voltage out of acceptable range | MCU Polling | ---- |
| 02/23/2018 15:53:06 | AC input frequency out of acceptable range | MCU Polling | ---- |
| 02/23/2018 15:53:06 | AC input has been detected for the island | MCU Polling | ---- |
| 02/23/2018 15:53:06 | AC input three phase dislocation | MCU Polling | ---- |
| 02/23/2018 15:53:06 | AC input wave terrible | MCU Polling | ---- |
| 02/23/2018 15:47:40 | Connect to time server error | SNTP | ---- |
| 02/23/2018 15:48:34 | Solar input 1 voltage exceed the acceptable range | MCU Polling | ---- |
| 02/23/2018 15:48:34 | Solar input 1 voltage exceed the highest level | MCU Polling | ---- |
| 02/23/2018 15:48:34 | AC input voltage lower than the lowest level of AC feeding voltage | MCU Polling | ---- |
| 02/23/2018 15:48:34 | AC input voltage lower than the lowest level of AC feeding frequency | MCU Polling | ---- |
| 02/23/2018 15:48:34 | AC input voltage out of acceptable range | MCU Polling | ---- |
| 02/23/2018 15:48:34 | AC input frequency out of acceptable range | MCU Polling | ---- |
| 02/23/2018 15:48:34 | AC input has been detected for the island | MCU Polling | ---- |
| 02/23/2018 15:48:34 | AC input three phase dislocation | MCU Polling | ---- |
| 02/23/2018 15:48:34 | AC input wave terrible | MCU Polling | ---- |
| 02/23/2018 15:48:41 | Connect to time server error | SNTP | ---- |
| 02/23/2018 15:52:03 | Solar input 1 voltage exceed the acceptable range | MCU Polling | ---- |
| 02/23/2018 15:52:03 | Solar input 1 voltage exceed the highest level | MCU Polling | ---- |
| 02/23/2018 15:52:03 | AC input voltage lower than the lowest level of AC feeding voltage | MCU Polling | ---- |
| 02/23/2018 15:52:03 | AC input voltage lower than the lowest level of AC feeding frequency | MCU Polling | ---- |
| 02/23/2018 15:52:03 | AC input voltage out of acceptable range | MCU Polling | ---- |
| 02/23/2018 15:52:03 | AC input frequency out of acceptable range | MCU Polling | ---- |
| 02/23/2018 15:52:03 | AC input has been detected for the island | MCU Polling | ---- |
| 02/23/2018 15:52:03 | AC input three phase dislocation | MCU Polling | ---- |
| 02/23/2018 15:52:03 | AC input wave terrible | MCU Polling | ---- |
| 02/23/2018 15:52:10 | Connect to time server error | SNTP | ---- |

Date log

Service Manual for Hybrid 30KW PV Inverter

SNMP Web Pro 1.1 Data log Login Guest


02_23_2018.csv

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20

| Time | PV voltage(V) | PV power(W) | Grid 1 voltage(V) | Grid 2 voltage(V) | Grid 3 voltage(V) | Grid frequency(Hz) | AC Output 1 voltage(V) | AC Output 2 voltage(V) | AC Output 3 voltage(V) | AC Output power(W) | AC Output frequency(Hz) | Load(%) | Battery voltage(V) |
|---------------------|---------------|-------------|-------------------|-------------------|-------------------|--------------------|------------------------|------------------------|------------------------|--------------------|-------------------------|---------|--------------------|
| 02/23/2018 15:51:34 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |
| 02/23/2018 15:52:35 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |
| 02/23/2018 15:48:33 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |
| 02/23/2018 15:49:32 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |
| 02/23/2018 15:50:34 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |
| 02/23/2018 15:51:34 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |
| 02/23/2018 15:52:33 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |
| 02/23/2018 15:48:24 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |
| 02/23/2018 15:49:26 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |
| 02/23/2018 15:50:26 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |
| 02/23/2018 15:51:25 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |
| 02/23/2018 15:52:27 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |
| 02/23/2018 15:48:25 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |
| 02/23/2018 15:49:24 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |
| 02/23/2018 15:50:26 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |
| 02/23/2018 15:51:26 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |
| 02/23/2018 15:52:26 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |
| 02/23/2018 15:48:16 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |
| 02/23/2018 15:49:18 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |
| 02/23/2018 15:49:18 | 0.0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 229.8 | 230.1 | 229.8 | 3 | 50.0 | 1 | 412.6 |

8. Change Single INVERTER to Parallel INVERTER

8.1 Overview




8.2 The hardware to install all hardware configurations



PARALLEL CONNECTION

15pins Female Pin Male Pin 15pins




Compared to the stand-alone INVERTER, a parallel board should be added to communication interface

8.3 Connect the power cable to the communication cable.

The capacity of the parallel INVERTER must be identical. According to wiring in the diagram below.

Service Manual for Hybrid 30KW PV Inverter



8.3.1 Input Cable

The input cable of each INVERTER to the power cable of the distribution cabinet should use the same diameter and length. Be sure to confirm the sequence of phase is the same.

8.3.2 Output Cable


The output of each INVERTER to the feeder cabinet power cable must use the same diameter and length. Be sure to confirm the sequence is consistent.

8.3.3 Battery Cable

INVERTER in the parallel system has its battery pack and the battery pack can be shared.


8.3.4 Communication Cable

a. The following parallel communication lines are about 5 meters long.




b. Connection of Communication cable

As shown in the diagram below, the parallel cables cross connect to form a circle. Use a screw to fix them firmly, and avoid communication failure because of loose cables



8.4 Parallel Adjustment (Take 2 stand-alone parallel as an example)

The default setting of the INVERTER is stand-alone. If you want to change it into parallel operation, you need to set the INVERTER in the display. You should have the service engineering code "XXXX" provided by the service engineer to execution the alternation. press <ENTER>, Go to the "Setting" and select "Advanced" Enter the password "0000" and set the "Others" of the INVERTER. Select "parallel" as shown below. Last, cut off the power and save.



Close the two INVERTER input switch and Battery(output switch off), the oscilloscope two probes were hooked up two INVERTER inverter capacitors at both ends, the INVERTER1 and INVERTER2 boot, the system are in the Inverter Mode output, observe oscilloscope Ch1 and Ch2 are synchronized (same frequency, same amplitude, same phase), as shown below. If they didn't synchronize, shut down the two INVERTER, check the wiring, and then repeat this steps until the two INVERTER synchronize.

Then the synchronization waveform is as follows: CH1 INVERTER inverter voltage, CH2 INVERTER inverter voltage.



If they synchronize, close the two INVERTER output switch and test and confirm the characteristics of exchange current.

INVERTER1 and Inverter2 are running in the inverter mode, with linear full load, and with the current clamp meter to measure and record the output current value of each phase of the two

INVERTER. Calculate the parallel load current imbalance required $\leq 5\%$, the formula is: $Y_i = \frac{I_o - I_m}{n \cdot I_o}$

Where, Y_i - load current unbalance (whichever is greater) I_o - Output current
 Other, I_m - parallel output of the maximum and minimum current in a single system: n - Number of INVERTER

- After shut down the Invertor1, lock the ones without output. The load is supplied by Invertor2.
- After shut down Invertor2., Invertor1 and Invertor2 turn into in Standby with PV charging mode.
- Invertor1 and Invertor2 are in parallel operation. At the time, both Invertor turn into inverter output. Each Invertor take 50% of the load.

9.Guidance of Single and Parallel System Maintenance & Operation at

Customer Site.

9.1 A separate system from the operation (Take INVERTER2 as an example)


- g. On the LCD screen of INVERTER2, press <ENTER> and go to "Control" in the main menu, and then press <ENTER> and select "Turn Off" and confirm the selection.
- h. Disconnect the output switch.
- i. Disconnect input switch
- j. Disconnect the PV switch
- k. Disconnect the battery switch
- l. The parallel system is powered by INVERTER1

9.2 Operation by a single system (Take INVERTER2 as an example)


- a. On the LCD screen of INVERTER2, press <ENTER> and go to "Control" in the main menu, and then press <ENTER> and select "Turn Off" and confirm the selection.
- b. Disconnect the output switch.
- c. Disconnect input switch
- d. Disconnect the PV switch
- e. Disconnect the battery switch
- f. The output R/S/T/N of INVERTER1 connect to the output R/S/T/N of INVERTER2, The same output phase is shorted together.
- g. Connect the battery switch
- h. Connect the PV switch
- i. Connect input switch
- j. Connect the output switch.
- k. On the LCD screen of INVERTER1 and INVERTER2, press <ENTER>, Go to the "Setting" and select "Advanced" Enter the password "0000" and set the "Others" of the INVERTER. Select "parallel"
- l. . Last, cut off the power and save.
- m. On the LCD screen of INVERTER1 and INVERTER2, press <ENTER> and go to "Control" in the main menu, and then press <ENTER> and select "Turn On" and confirm the selection.
- g.The parallel system is supplied by INVERTER1 and INVERTER2 simultaneously.

10. PCB Layout

Control Board




Power Board




Service Manual for Hybrid 30KW PV Inverter


Communication Board



SCR Driver



Inverter Control Board



Voltage Sampling Board

