



INSTALL THE END CLAMP BY SLIDING THE TAG UNDER THE A-FRAMES FRAME AND FASTEN THE BOLT ONTO THE TAG FROM ABOVE. MAKE SURE THE ALUMINIUM SPACER IS PRESSED AGAINST THE PANEL WHEN FASTENING THE END CLAMP.  
**TIGHTEN TO 8Nm**