


CCGX dongle for large VE.Bus systems



Instructions:

- Use this dongle in VE.Bus systems consisting of 5 or more Multis or Quattros. How these devices are configured, in parallel or multiple-phase, is not important.
- Without this dongle it is not always possible to switch a system back on after switching it off from the Color Control GX menus.
- Connect only the dongle to the CCGX: leave the other VE.Bus socket on the CCGX open.

e.g. to VE.Bus BMS
or VE.Bus remote
panel etc.

CCGX dongle for large VE.Bus systems
PN: BPP900300100